



MVC Feedforward (Motion Vibration Control)



Application Note



www.agito-akribis.com

Member of Akribis Systems group

Revision History

Version	Description	Date
1.0	Initial Release	14 February 2022

Contact Information

Manufacturer	Agito Akribis Systems Ltd., Member of Akribis Systems Group
Address	6 Yad-Harutsim St., P.O.Box 7172, Kfar-Saba 4464103
Telephone	+972-9-8909797
Website	www.agito-akribis.com

Copyright Notice

©2023 Agito Akribis Systems Ltd.

All rights reserved. This work may not be edited in any form or by any means without written permission of Agito Akribis Systems Ltd.

Products Rights

AGDx, AGCx, AGMx, AGAx, AGIx, and AGLx are products designed by Agito Akribis Systems Ltd. in Israel. Sales of the products are licensed to Akribis Systems Pte Ltd. under intercompany license agreement.

Agito Akribis Systems Ltd. has full rights to distribute above products worldwide.

Disclaimer

This product documentation was accurate and reliable at the time of its release.

Agito Akribis Systems Ltd. reserves the right to change the specifications of the product described in this manual without notice at any time.

Trademarks

Agito PCSuite is a trademark of Agito Akribis Systems Ltd..

Warranty

This product is warranted to be free of defects in material and workmanship and conforms to the specifications listed in this manual, for a period of 12 months from the shipment date from factory.

Contents

1	Introduction	4
1.1	Background	4
1.2	Scope	4
2	Setup	5
2.1	Setup	5
2.2	AGD155 Wiring	5
2.3	MVC Wiring	5
2.4	Ratio of MVC input to current output	6
2.5	Controller setup	7
2.6	Verification	7

1 Introduction

1.1 Background

Base oscillations are prominent in systems with relatively high payload and accelerations and relatively low base stiffness. Stages with dual carriages or multiple machines working on the same base are also prone to such base oscillations.

This can affect performance such as settling time and jitter. Motion Vibration Control is a tool that can be used to detect and compensate for such vibrations.

1.2 Scope

This application note seeks to explain the steps to connect an MVC sensor to an Agito driver, and how to setup the driver to compensate for the vibrates using a feedforward.

2 Setup

2.1 Setup

Connect the stage to the Agito driver. Additionally, mount the MVC sensor onto the base and connect it to any of the analog inputs on the driver.




Figure 1. Stage Setup

2.2 AGD155 Wiring

Function	Pin Name	Pin #	AGD155 Connector
Analog Input +	Analog_Input_1	6	X6
Analog Input -	Analog_Input_Return_1	7	X6
5V	Supply Output 5V	36	X6
GND	Supply Output 0V	28	X6

2.3 MVC Wiring

Function	Pin Name	Pin #	MVC Connector
Analog Output +	Differential Analog Out +	14	D-Sub 15 Male
Analog Output -	Differential Analog Out -	15	D-Sub 15 Male
5V	Supply Input 5V	12	D-Sub 15 Male
GND	Supply Input 0V	13	D-Sub 15 Male

2.4 Ratio of MVC input to current output

Before the compensation feature can be used, the user will need to find the relationship between how much current to compensate for based on the reading from the MVC. The easiest method would be to do an experiment.

Firstly, tune the gains to a level which is able to reject the disturbance even without the feature. It is okay to have some noise at this stage, as we only want to measure the current needed to generate an opposite force on the base.

Next, make a motion to inject the disturbance, and do a recording of the following parameters,

- Analog input
- Current reference
- Position Error

The controller will try to reject the disturbance via the PIV control and the current will increase to overcome the force applied by the base oscillation.






Figure 2. Controller Setup

In the example above, the current profile matches the MVC profile with a lag. Taking a simple peak-peak ratio, we get 437.5mV to 600mA. The gain is 1.37mA/mV.

2.5 Controller setup



Navigate to  then . In this page you will be able to configure the analog input to do torque compensation using the MVC sensor. Set the Input Mode to 6 – Torque Compensation. Adjust the signal conditioning parameters accordingly.




Figure 3. Controller Setup – Analog Input



Navigate to  then . Set the TorqCompMode to 0 – Use analog input.

Torque compensation and limitations

Torque comp. mode:

Figure 4. Controller Setup - More

After applying the settings, the torque compensation will take effect.

2.6 Verification

Adjust the PIV gains to a desired level. Repeat the same experiment to create the disturbances and check if the performance has improved. Continue adjusting the gains of the torque compensation feature.

